



Part No.	Part Name
81051	BRASS BAIL SCREW NO. 1
81068	TRIP LEVER & SPRING SCREW
81419	BAIL ARM LOCK NUT
81453	BRASS SIDE PLATE SCREW
81455	OSCILLATION SLIDE LOCK
81456	OSCILLATION SLIDE
81460	STEEL ANTI-REVERSE DOG
81461	ANTI-REV. DOG SPRING
81470	STEEL BAIL SPRING
81476	BRASS ROLLER LINE GUIDE
81477	BAIL WIRE LOCK WASHER
81478	BAIL WIRE LOCK NUT
81481	STEEL CLICK SPRING
81482	LEATHER DRAG DISC
81483	AXLE WITH RATCHET
81486	BRASS HEX NUT
81487	STEEL KEYED WASHER
81491	BRASS BRAKE DRUM SCREW
81493	STEEL BALL BEARING
81500	STEEL UTILITY TOOL
81503	BRAKE DRUM
81504	STEEL BRAKE SPRING
81505	BRAKE SHOE
81509	STEEL TRIP LEVER SPRING
81510	BRACKT COUNTRWT SCREW
81511	STEEL BAILWIRE BRACKET
81513	STEEL BAIL WIRE
81515	STEEL TRIP LEVER

Part No.	Part Name
81516	STEEL TRIP LEVER AXLE
81517	STEEL BAILMOUNT BRACKET
81518	BRASS BAIL WIRE MOUNT
81520	BRASS BAIL MOUNT SCREW
81522	BRASS COUNTER WEIGHT SCREW
81523	BRASS COUNTER WEIGHT
81533	DRIVE GEAR BEARING
81537	BRASS PINION GEAR
81976	ANTI-REVERSE LEVER
81977	RUBBER O-RING
81978	BRONZE ANTI-REV. WASHER
81980	ANTI-REVERSE CAM
81981	ANTI-REV. LOCK WASHER
81982	ANTI-REVERSE LOCK NUT
82427	FIBRE COVER PLATE SEAL
82715	DRAG ADJUSTING KNOB
82716	ALUM.ALLOY SIDE PLATE
82740	SPOOL—STD ALUMINUM ALLOY
82743	ALUM.ALLOY ROTATING HEAD
82959	HANDLE COMPLETE
83119	DRAG WASHER
83190	OIL DUST SHIELD
83482	BRASS SHIMS/ADJ. DR. GR.
83485	HOUSING/NEEDLE CASING
83520	BRONZE DRIVE GEAR
84546	BRASS HANDLE COUNTERWEIGHT
84552	BRASS HANDLE CORE
84553	HANDLE ARM